


GA-35RVT



- | | | | | |
|--------------|-----------------------------------|----------------|------------|------------------------|
| T1 | Power Transformer | TF-104P | D1A,B | Diode - 1200 PIV DI-S7 |
| T2 | Output Transformer | TF-P6417 | D2 | Diode 600 PIV DI-71B |
| T3 | PP Driver Transformer | TF-1001D-1 | | |
| T4 | Reverb Transformer | TF-E6400 | | |
| L1 | Filter Choke | TF-3021H | | |
| S1A,E,C,D | Switch - off, standby, on-On | SW-78A-1 | | |
| S2,S3 | Switches - SPST | SW-82403 | | |
| I1 | PL-37R Pilot Light (Red) | X1 | CN-78PCG-5 | Foot Pedal Socket |
| I2 | PL-38A Pilot Light (Ammbr) | X2 | Ch-303 | AC Convenience Outlet |
| R9, R30, R54 | Control - 250K, Audio | CBA-4008 | | |
| R8, R26 | Control - 2 meg, audio | CBA-911-3702-1 | | |
| R44 | Control - 500K Audio | CBA-4007 | | |
| R55 | Control - 1.5 meg, R _h | CBA-911-3711-1 | | |
| R7, R28 | Control - 1 meg, audio | CBA-911-3709-1 | | |

For Parts Call
Parts is Parts
802-464-0014
800-590-0014

email info@guitar-parts.com